



HEATHKIT

PARTS LIST

54 - POWER TRANSFORMERS

P/N	Description	Used In
54-1	Power Transformer (P: 115V; S: w/ Taps @ 350V & 700V@30mA, 1275V@3mA & 1280V@2A; 6.3V@3.5A, 6.3V@600mA, 5V@2A)	O-7
54-2	Power Transformer (P: 117V; S: 120V@10mA, 6.3V@800mA)	AV-1, AV-2, AV-3, CA-1, GD-125, IB-2, IM-13, IM-21, IM-21E, IM-28, SG-7, SG-8, TO-1, V-6, VC-2
54-2-24	Power Transformer (P: 115/230V; S: 130V@10mA, 6.3V@800mA)	IM-28, IM-38, IM-5228, IT-7400
54-3	Power Transformer (P: 117V; S: 700V@50mA CT, 5V@2A, 12.6V@1A)	AR-2
54-4	Power Transformer (P: 117V; S: 648V CT, 6.3V CT, 5V)	A-8, A-9A
54-5	Power Transformer (P: 117V; S: 464V@60mA CT, 6.3V@2.8A)	AA-1, AG-8, IM-12, IM-22, IM-58, QM-1, TS-3, TS-4, TS-4A
54-5-24	Power Transformer (P: 110/220V; S: 464V@60mA CT, 6.3V@2.8A)	IM-12E
54-6	Power Transformer (P: 117V; S: 550V@30mA CT, 6.3V@1.5A)	AO-1
54-7	Power Transformer (P: 117V; S: 535V@5mA, 55V@10mA, 12.6V@400mA)	C-3, CT-1, IT-22
54-7-24	Power Transformer (P: 115/230V; S: 535V@5mA, 55V@10mA, 12.6V@400mA)	
54-8	Power Transformer (P: 125V w/ Tap @100V; S: 250V w/ Taps @ 30 & 100V; 110V w/ Taps @ .75, 1.4, 2, 2.5, 3.3, 5, 6.3, 7.5, 12.6, 25, 32, 50 & 70V)	TC-2
54-12	Power Transformer (P: 117V; S: 12V@10A w/Variable Taps)	BE-3, BE-4, BE-5
54-12-24	Power Transformer (P: 115/230V; S: 12V@10A w/Variable Taps)	
54-13	Power Transformer (P: 115V; S: 810V@135mA CT, 5V@3A, 6.3V@4A CT)	A-9, A-9B, A-9C, W-2, W-3, W-3AM, W-3M
54-14	Power Transformer (P: 115V; S: 700V@140mA CT, 2.5V, 5V, 6.3V@500mA, 6.3V@4A)	PS-2, PS-3
54-15	Power Transformer (P: 117V; S: 530V CT, 12.6V CT)	T-3
54-16	Wattmeter Transformer (P: 117V)	T-3
54-17	Power Transformer (P: 117V; S: 100V@10mA, 5.5V@220mA)	GD-1, GD-1A, GD-1B
54-17-24	Power Transformer (P: 115/230V; S: 100V@10mA, 5.5V@220mA)	
54-18	Power Transformer (P: 115V; S: w/ Taps @ 350V & 700V@30mA, 1275V@3mA & 1280V@2A; 6.3V@3.5A; 6.3V@600mA; 5V@2A)	O-8
54-19	Power Transformer (P: 115V; S: w/ Taps @ 350V & 700V@100mA, 1275V@3mA & 1280V@2A; 6.3V@3.5A; 6.3V@600mA; 5V@2A)	O-9
54-20	Power Transformer	
54-21	Power Transformer (P: 117V; S: 860V@110mA CT, 5V@3A, 6.3V@3A)	AT-1
54-22	Power Transformer (P: 117V; S: 125V@80mA, 6.3V@2.5A)	IG-42, LG-1
54-22-24	Power Transformer (P: 120/240V; S: 125V@80mA, 6.3V@2.5A)	IG-42
54-23	Power Transformer (P: 117V; S: 120V@10mA, 6.3V@800mA)	EUW-24, IM-11, IM-11D, IM-18, V-7A
54-23-24	Power Transformer (P: 120/240V; S: 120V@10mA, 6.3V@800mA)	IM-18, SM-20A
54-24	Power Transformer (P: 115V; S: w/ Taps @ 360V & 720V@35mA, 1230V@3mA, 1230.625V@300mA; 6.3V@2A; 6.3V@600mA)	OL-1
54-25	Power Transformer (P: 115V)	A-7
54-26	Power Transformer (P: 115V; S: w/ Taps @ 400V & 800V@80mA, 1450V@3mA, 1450.625V@600mA; 6.3V@3.5A CT; 6.3V@600mA)	O-10, O-11, O-12
54-26-24	Power Transformer (P: 115/230V; S: w/ Taps @ 400V & 800V@80mA, 1450V@3mA, 1450.625V@600mA; 6.3V@3.5A CT; 6.3V@600mA)	
54-28	Power Transformer (P: 115V; S: w/ Taps @ 300V & 600V@35mA, 1200V@3mA, 1200.625V@300mA; 6.3V@2.5A; 6.3V@600mA)	OM-1
54-29	Power Transformer (P: 115V; S: 760V@130mA CT, 6.3V@4A CT, 5V@3A)	W-4AM
54-30	Plate Transformer (P: 115V; S: 1800V@400mA CT)	DX-100, TX-1
54-30-24	Plate Transformer (P: 115/230V; S: 1800V@400mA CT)	
54-31	Power Transformer (P: 110V; S: 634V@150mA CT w/ 2 Taps 120V@20mA, 5V@2A, 5V@4A, 12.6V@4A CT)	DX-100
54-32	Power Transformer (P: 117V; S: 910V@140mA CT, 6.3V@4A CT, 5V@3A)	W-5M
54-33	Power Transformer	
54-34	Power Transformer (P: 117V@480mA; S: 480V@60mA CT, 6.3V@3.2A)	BC-1A, CM-1, FM-3A, GW-12, GW-12A, GW-12D, GWW-12A, GWW-12D, ID-22, IT-11
54-34-24	Power Transformer (P: 120/240V; S: 475V@60mA CT, 6.3V@3.2A)	IT-11, IT-28
54X-34	Power Transformer (P: 110/220V; S: 480V@60mA CT, 6.3V@3.2A)	ID-22E
54-35	Power Transformer (P: 115V; S: 710V@50mA CT, 6.3V@1.5A)	
54-36	Power Transformer (P: 117V; S: 500V, 12.6V, 5V)	AR-3
54-37	Filament Transformer (P: 115V; S: 6.3V@300mA)	TX-1
54-37-24	Filament Transformer (P: 115/230V; S: 6.3V@300mA)	

P/N	Description	Used In
54-38	Power Transformer (P: 115V; S: 1460V@150mA CT, 6.3V@3.2A, 6.3V@650mA, 5V)	DX-35, DX-40
54-39	Power Transformer	
54-40	Power Transformer (P: 117V; S: 520V CT, 6.3V)	XO-1
54-41	Power Transformer (P: 117V; S: 117V@20mA)	
54-42	Power Transformer (P: 117V; S: 6.3V@1.5A)	ES-600
54-43	Power Transformer	
54-44	Power Transformer	
54-45	Filament Transformer	
54-46	Filament Transformer	
54-47	Power Transformer	
54-48	Power Transformer	
54-49	Power Regulator	
54-51	Power Transformer (P: 115V; S: 2100V@340mA w/Taps, 6.3V@3A, 6.3V@600mA)	
54-52	Power Transformer	
54-54	Power Transformer (P: 117V; S: 1200V@120mA CT, 5V@3A, 6.3V@2A)	DX-20
54-55	Power Transformer (P: 117V; S: 741V@3A w/ Taps, 6.3V@3A, 6.3V@600mA)	
54-55-24	Power Transformer (P: 115/230V; S: 741V@3A w/Taps, 6.3V@3A, 6.3V@600mA)	
54-56	Power Transformer (P: 117V; S: 120V@10mA, 20V@150mA)	IB-2A
54-56-24	Power Transformer (P: 120/240V; S: 120V@10mA, 20V@150mA)	IB-28
54-57	Power Transformer (P: 117V; S: 640V@60mA CT, 6.3V@2A)	AG-9A, IG-72
54-57-24	Power Transformer (P: 115/230V; S: 640V@60mA CT, 6.3V@2A)	
54X-57	Power Transformer (P: 115/230V; S: 640V@60mA CT, 6.3V@2A)	IG-72E
54-58	Power Transformer (P: 117V; S: 170V@350mA, 130V@35mA, 6.3V@5.5A CT)	W-6A
54-59	Power Transformer (P: 117V; S: 117V@98mA, 6.3V@3.8A)	AG-10, EUW-27, IG-62, IG-82
54-59-24	Power Transformer (P: 115/230V; S: 117V@98mA, 6.3V@3.8A)	
54-60	Power Transformer	
54-63	Power Transformer (P: 117V; S: 650V@130mA CT, 6.3V@3.8A)	EA-2, EA-3, UA-1
54-63-24	Power Transformer (P: 115/230V; S: 650V@130mA CT, 6.3V@3.8A)	
54-64	Power Transformer (P: 117V; S: 117V@45mA, 12.6V@1A)	IT-12, T-4
54-64-24	Power Transformer (P: 110/220V; S: 117V@45mA, 12.6V@1A)	IT-12, IT-12E
54-65	Power Transformer (P: 115V; S: 600V@175mA CT w/ 2 Taps @ 240V@20mA, 6.3V@9A, 6.3V@3.5A, 5V@4A, 5V@2A)	TX-1
54-65-24	Power Transformer (P: 115/230V; S: 600V@175mA CT w/ 2 Taps @ 240V@20mA, 6.3V@9A, 6.3V@3.5A, 5V@4A, 5V@2A)	
54-66	Power Transformer (P: 117V; S: 420V@150mA CT, 6.3V@5A, 5V@2A)	RX-1
54-67	Power Transformer (P: 110V; S: 120V@20mA, 6V@1.5A)	VX-1
54-68	Power Transformer (P: 117V; S: 180V@250mA, 40V@5mA, 6.3V@3.5A)	W-7A
54-69	Power Transformer (P: 120V; S: 1826V w/ Taps @210mA, 170V@1.8A, 117V@60mA, 6.3V@6A)	
54-70	Power Transformer (P: 117V; S: 80V@130mA, 6.3V@5.5A)	PT-1
54-70-24	Power Transformer (P: 115/230V; S: 80V@130mA, 6.3V@5.5A)	
54-71	Power Transformer (P: 117V; S: 120V@12mA, 2 x 6.3V@1A)	AA-20, AA-141A, SP-2, SP-2A
54-72	Power Transformer (P: 115V w/ Taps @ 95 to 135V in 5V Steps; S: 250V w/ Taps @ 30V & 100V; 110V w/ Taps @ .63, 1.4, 2, 2.35, 2.5, 3.15, 4.2, 4.7, 5, 6.3, 7.5, 9.45, 12.6, 19.6, 25, 32, 50 & 70V)	IT-17, IT-21, TC-3
54-73	Power Transformer (P: 117V; S: 1640V@250mA CT, 800V@95mA CT, 6.3V@6.5A, 2 x 5V)	VHF-1
54-74	Inverter Power	
54-75	Power Transformer	
54-76	Filament Transformer (P: 117V; S: 6.3V@4.15A, 6.3V@2A, 6.3V@600mA, 6.3V@150mA)	EC-1, IP-32
54-76-24	Filament Transformer (P: 110/220V; S: 6.3V@4.15A, 6.3V@2A, 6.3V@600mA, 6.3V@150mA)	

P/N	Description	Used In
54X-76	Filament Transformer (P: 110/220V; S: 6.3V@4.15A, 6.3V@2A, 6.3V@600mA, 6.3V@150mA)	IP-32E
54-77	Power Transformer (P: 117V; S: 600V@30mA CT, 210V@120mA, 175V@15mA)	IP-32
54-77-24	Power Transformer (P: 110/220V; S: 600V@30mA CT, 210V@120mA, 175V@15mA)	
54X-77	Power Transformer (P: 110/220V; S: 600V@30mA CT, 210V@120mA, 175V@15mA)	IP-32E
54-78	Plate Transformer (P: 117V; S: 220V@35mA, 200V@40mA, 3 x 150V@17mA, 125V@15mA)	EC-1
54-78-24	Plate Transformer (P: 110/220V; S: 220V@35mA, 200V@40mA, 3 x 150V@17mA, 125V@15mA)	
54-80	Plate Transformer (P: 117V; S: 1300V@300mA, 175V@75mA, 117V@60mA, 6.3V)	
54-80-24	Plate Transformer (P: 110/220V; S: 1300V@300mA, 175V@75mA, 117V@60mA, 6.3V)	
54-81	Plate Transformer (P: 110V; S: 117V@40mA, 6.3V@2A)	
54-81-24	Plate Transformer (P: 110/220V; S: 117V@40mA, 6.3V@2A)	
54-82	Plate Transformer	
54-83	Filament Transformer	
54-84	Bias Supply	
54-85	Filament Transformer	KS-1
54-86	Plate Transformer	KS-1
54-87	Power Transformer (P: 117V@340mA; S: 100V@200mA, 6.3V@1.9A)	CB-1, HW-19, HW-29, HW-29A, HW-30, W-CB-1
54-88	Power Transformer (P: 117V; S: 255V@300mA, 2 x 6.3V@4A)	
54-89	Power Transformer (P: 117V; S: 740V@270mA CT + Tap@50V, 2 x 6.3V@3.2A, 5V)	AA-50, AA-100
54-89-24	Power Transformer (P: 115/230V; S: 740V@270mA CT + Tap@50V, 2 x 6.3V@3.2A, 5V)	
54-91	Power Transformer (P: 117V; S: 540V@110mA CT, 6.3V@3.5A)	
54-91-24	Power Transformer (P: 115/230V; S: 540V@110mA CT, 6.3V@3.5A)	
54-92	Power Transformer (P: 117V; S: 120V@20mA, 6.3V@800mA)	EF-1, FMO-1, IG-102, RF-1, SB-630
54-92-24	Power Transformer (P: 120/240V; S: 120V@20mA, 6.3V@800mA)	IG-102, SB-630
54-93	Power Transformer (P: 117V; S: 620V@170mA CT, 2 x 6.3V@2.5A, 5V@1.9A)	AA-151, SA-2
54-94	Power Transformer (P: 115V; S: 115V w/ Taps @ .65, 1.1, 1.5, 2, 2.5, 3.3, 5, 6.3, 7.5, 10, 13, 20, 27.5, 35, 47 & 70V; 3 Other Windings)	TT-1
54-96	Power Transformer (P: 115V; S: 19.2V@220mA CT)	AJ-14, SW-717, XP-2
54-96-24	Power Transformer (P: 115/230V; S: 19.2V@220mA CT)	
54-97	Power Transformer (P: 117V; S: 384V@48mA CT, 6.3V@2A, 5V@2A)	EK-2A
54-97-24	Power Transformer (P: 115/230V; S: 384V@48mA CT, 6.3V@2A, 5V@2A)	
54-98	Power Transformer (S: 117V)	MP-10
54-99	Power Transformer (P: 117V; S: 90V + 7 x 5.2V Taps + 7 x 0.75V Taps)	IP-10, IP-22
54-100	Power Inverter 110V	
54-100-24	Power Inverter 220V	
54-101	Power Transformer (P: 117V; S: 55V@75mA, 6.3V@4.3A)	AJ-11
54-101-24	Power Transformer (P: 115/230V; S: 55V@75mA, 6.3V@4.3A)	
54-102	Power Transformer (P: 117V; S: 190V@350mA, 45V@10mA, 6.3V@4A, 6.3V)	AA-121
54-102-24	Power Transformer (P: 115/230V; S: 190V@350mA, 45V@10mA, 6.3V@4A, 6.3V)	
54-103	Power Transformer (P: 117V; S: 1380.625V w/ 3 Taps (330V & 660V)@85mA & 1380V@3mA & 0.625V@300mA; 6.3V@600mA, 6.3V@3.5A CT)	IO-12, IO-30
54-103-24	Power Transformer (P: 120/240V; S: 1380.625V w/ 3 Taps (330V & 660V)@85mA & 1380V@3mA & 0.625V@300mA; 6.3V, 6.3V@3.5A CT)	IO-18, IOB-18-3
54-104	Power Transformer (P: 117V; S: 1300.625V w/ Taps @ (325V, 650V, 1300V)@80mA & 0.625V@300mA; 120V@60mA, 6.3V@600mA, 6.3V@3.6A CT)	EUW-25
54-104	Power Transformer (P: 117V@440mA; S: 100V@250mA, 6.3V@3A)	GW-10A, GWW-10A

P/N	Description	Used In
54-105	Power Transformer (P: 117V; S: 1500.625V w/ Taps @ (325V & 650V)@60mA, 1500V, 0.625V@300mA; 120V@60mA, 6.3V@600mA, 6.3V@3.6A CT)	IO-10
54-105-24	Power Transformer (P: 120/240V; S: 1500.625V w/ Taps @ (325V & 650V)@60mA, 1500V, 0.625V@300mA; 120V@60mA, 6.3V@600mA, 6.3V@3.6A CT)	IO-10
54-106	Power Transformer	
54-107	Power Transformer	
54-108	Power Transformer (P: 117V; S: 1800.63V w/ 2 Taps @ (90V & 1800V) & 0.63V@300mA; 6.3V@2A; 6.3V@600mA)	IO-20
54-108-24	Power Transformer (P: 120/240V; S: 1800.63V w/ 2 Taps @ (90V & 1800V) & 0.63V@300mA; 6.3V@2A; 6.3V@600mA)	IO-20
54-109	Power Transformer (P: 117V; S: 260V@600mA, 110V@30mA, 2 x 6.3V@4A)	DX-60, HA-20, HP-20
54-109-24	Power Transformer (P: 120/240V; S: 260V@600mA, 110V@30mA, 2 x 6.3V@4A)	
54-110	Plate Transformer (P: 117V; S: 3400V@500mA CT)	HA-10
54-110-24	Plate Transformer (P: 120/240V; S: 3400V@500mA CT)	
54-111	Filament Transformer (P: 117V; S: 2.5V@10A)	HA-10
54-112	Filament & Bias Transformer (P: 117V; S: 10V@500mA, 6.3V@16A CT)	HA-10
54-112-24	Filament & Bias Transformer (P: 120/240V; S: 10V@500mA, 6.3V@16A CT)	
54-113	Filament Transformer (P: 117V; S: 6.3V@1A)	HX-10
54-113-24	Filament Transformer (P: 120/240V; S: 6.3V@1A)	
54-114	Power Transformer (P: 117V; S: 1880V@200mA CT, 814V@180mA CT, 222V@25mA CT, 6.3V@9A, 5V@2A, 5V@3A)	HX-10
54-114-24	Power Transformer (P: 120/240V; S: 1880V@200mA CT, 814V@180mA CT, 222V@25mA CT, 6.3V@9A, 5V@2A, 5V@3A)	
54-115	Power Transformer (P: 120V; S: 12V@1.5A)	GD-1776, GR-110
54-116	Power Transformer (P: 120V; S: 705V@120mA CT, 2 x 6.3V@1.6A, 5V)	
54-116-24	Power Transformer (P: 120/240V; S: 705V@120mA CT, 2 x 6.3V@1.6A, 5V)	
54-117	Power Transformer (P: 117V; S: 142V@80mA, 6.3V@2.9A)	GR-21
54-117-24	Power Transformer (P: 120/240V; S: 142V@80mA, 6.3V@2.9A)	IG-37
54-118	Power Transformer (P: 117V; S: 705V@160mA CT + Tap@48V, 6.3V@2.5A, 5V@1.9A)	AA-23, AA-181
54-118-24	Power Transformer (P: 120/240V; S: 705V@160mA CT + Tap@48V, 6.3V@2.5A, 5V@1.9A)	
54-119	Power Transformer (S: 1176V@320mA, 6.3V@2.1A, 6.3V@600mA)	
54-119-24	Power Transformer (S: 1176V@320mA, 6.3V@2.1A, 6.3V@600mA)	
54-120	Power Transformer (P: 117V; S: 123V@25mA, 55.6V@900mA CT)	AA-11
54-120-24	Power Transformer (P: 120/240V; S: 123V@25mA, 55.6V@900mA CT)	
54-121	Isolation Transformer (P: 117V; S: 118V@230mA)	GR-10, GR-81, GR-91, GR-121
54-121-24	Isolation Transformer (P: 120/240V; S: 118V@230mA)	
54-122	Power Transformer (P: 117V; S: 410V@63mA CT, 6.3V@4A)	
54-122-24	Power Transformer (P: 120/240V; S: 410V@63mA CT, 6.3V@4A)	GR-54, HR-10B
54-123	Power Transformer (P: 117V; S: (10, 15, 20, 25, 29, 33, 38, 43, 47, 53V)@1.5A, 170V@43mA, 7.1V@32mA)	IP-20
54-124	Power Transformer (P: 117V@580mA; S: 105V@50mA, 6.3V@3.6A)	GW-11A, GW-22A, GWW-11A, GWW-22A
54-124-24	Power Transformer (P: 120/240V@580mA; S: 105V@50mA, 6.3V@3.6A)	
F54-124	Power Transformer (P: 117V@560mA; S: 100V@220mA, 6.3V@3.4A)	GWW-22A
54-125	Power Transformer (P: 117V; S: 52V@73mA CT, 6.3V@600mA)	
54-125-24	Power Transformer (P: 120/240V; S: 52V@73mA CT, 6.3V@600mA)	
54-126	Power Transformer (P: 117V; S: 80V@130mA, 6.3V@7A)	AJ-41
54-126-24	Power Transformer (P: 120/240V; S: 80V@130mA, 6.3V@7A)	
54-127	Power Transformer (P: 115V w/ 2 Taps; S: 200V@15mA, 180V@120mA CT, 6.3V@3.5A CT, 6.3V@3A)	EUW-15
54-128-24	Power Transformer (P: 120/240V; S: 200V@10mA, 2 x 160V@70mA)	
54-129	Filament Transformer (P: 120/240V; S: 6V@4.1A CT; 6.3V@950mA, 6.3V@800mA)	EUW-19B

P/N	Description	Used In
54-129-24	Filament Transformer (P: 120/240V; S: 6V@4.1A CT; 6.3V@950mA, 6.3V@800mA)	
54-130	Power Transformer (P: 110V; S: 1200V@1mA w/ Tap @1199.2V, 220V@25mA, 2 x 6.3V@2.6A)	HO-10, HO-13
54-130-24	Power Transformer (P: 120/240V; S: 1200V@1mA w/ Tap @1199.2V, 220V@25mA, 2 x 6.3V@2.6A)	
54-131	Power Transformer (P: 117V; S: 50V@200mA CT)	EUW-17
54-132	Power Transformer (P: 120/240V; S:100V@5mA MT)	EUW-19B
54-133	Power Transformer (P: 117V; S: 114V@30mA, 6.3V@900mA, 6.3V@600mA, 6.3V)	
54-134	Power Transformer (P: 117V; S: 258V@40mA)	EUW-16
54-135	Power Transformer (P: 117V; S: 496V@170mA CT + 1 Tap, 6.3V@6A)	HX-30
54-135-24	Power Transformer (P: 120/240V; S: 496V@170mA CT + 1 Tap, 6.3V@6A)	
54-136	Power Transformer (P: 117V; S: 6V@4.1A)	
54-137	Power Transformer (P: 120V; S: 82V@70mA, 6.3V@4.3A)	AJ-12
54-137-24	Power Transformer (P: 120/240V; S: 82V@70mA, 6.3V@4.3A)	
54-138	Power Transformer (P: 117V; S: 570V@300mA CT, 6.3V@9A, 5V@3A)	
54-139	Power Transformer (S: 5V@50mA)	
54-140	Power Transformer (S: 15V@15A CT)	
54-140-24	Power Transformer (S: 15V@15A CT)	
54-141	Transformer (S: 300V@100mA)	
54-142	Power Transformer (P: 117V; S: 119V@85mA, 6.3V@1.5A, 6.3V@1.3A)	
54-143	Power Transformer (P: 120V; S: 268V@250mA, 125V@150mA w/ Tap @95V, 12.6V@5A CT)	HP-23
54-143	Power Transformer (P: 120V; S: 282V@250mA, 124V@150mA CT, 12.6V@5A CT)	SB-400, SB-401
54-143-24	Power Transformer (P: 120/240V; S: 282V@250mA, 124V@150mA CT, 12.6V@5A CT)	
54-144	Toroid-Type Power Transformer (1.5kHz) (S: 820V@250mA, 325V@150mA w/ Tap, 320V@20mA)	HP-13, HP-13A
54-145	Power Transformer (P: 117V; S: 29V@150mA, 6.3V@600mA)	AJ-43D
54-146	Power Transformer (P: 120V; S: 232V@170mA CT, 6.3V@5A)	SB-300
54-146-24	Power Transformer (P: 120/240V; S: 232V@170mA CT, 6.3V@5A)	SB-301, SB-310
54-147	Power Transformer (P: 120V; S: 64V@300mA CT, 36V@1.6A CT)	AR-12A
54-147-24	Power Transformer (P: 120/240V; S: 64V@300mA CT, 36V@1.6A CT)	
54-148-24	Auto-Transformer (117V@4.3A)	
54-149	Power Transformer (P: 120V; S: 154V@450mA, 6.3V@14A, 6.3V@1.2A)	GR-180
54-150	Power Transformer (P: 120V; S: 120V@150mA; 6.3V@4A)	
54-150-24	Power Transformer (P: 120/240V; S: 120V@150mA; 6.3V@4A)	AA-32
54-151	Power Transformer (P: 120/240V; S: 800V@500mA, 120V@60mA, 6.3V@8A CT)	SB-200, SB-201
54-152	Power Transformer (P: 120/240V; S: 100V@40mA; 6.3V@1.5A)	EUW-20A, EUW-20AE
54-153	Power Transformer (P: 120V; S: 88V@60mA; 6.3V@3A)	
54-153-24	Power Transformer (P: 120/240V; S: 88V@60mA; 6.3V@3A)	
54-155	Power Transformer (P: 120V; S: 105V, 12V)	GR-64
54-155-24	Power Transformer (P: 120/240V; S: 105V@60mA, 12.6V@1A)	
54-156	Power Transformer (P: 120V; S: 13.3V@5mA)	GD-97, HD-10
54-157	Power Transformer (P: 120V; S: 1300V@5mA, 174V@30mA, 97V@20mA, 26V)	
54-157-24	Power Transformer (P: 120/240V; S: 1300V@5mA, 174V@30mA, 97V@20mA, 26V)	
54-158	Power Transformer (P: 120V; S: 52V@2.4A CT, 6.3V@600mA)	
54-158-24	Power Transformer (P: 120/240V; S: 52V@2.4A CT, 6.3V@600mA)	
54-159	Power Transformer (P: 120/240V; S: 800V@500mA, 100V@60mA, 12.6V@4A)	HP-24
54-160	Toroid-Type Power Transformer (1.5kHz) (S: 2000V@150mA, 250V@60mA)	HP-14
54-161	Power Transformer (P: 120V; S: 740V@250mA)	

P/N	Description	Used In
54-162	Power Transformer (P: 117V; S: 264V@48mA)	EUW-16A
54-163	Power Transformer (P: 120V; S: 28V@1.5A)	
54-163-24	Power Transformer (P: 120/240V; S: 28V@1.5A)	
54-164	Power Transformer (P: 120V; S: 43V@170mA CT)	GWA-14-1
54-164-24	Power Transformer (P: 120/240V; S: 43V@170mA CT)	
54-165	Power Transformer (P: 120V; S: 200V@180mA, 185V@150mA, 140V@80mA)	
54-166	Power Transformer (P: 120V; S: 23V@260mA CT)	
54-167	Power Transformer (P: 120V; S: 38V@260mA CT)	
54-168	Power Transformer (P: 120V; S: 600V@1mA, 210V@25mA, 6.3V@2.6A, 6.3V)	
54-168-24	Power Transformer (P: 120/240V; S: 600V@1mA, 210V@25mA, 6.3V@2.6A, 6.3V)	
54-169	Auto-Transformer (115V@870mA)	
54-170	Power Transformer (P: 120V; S: 532V@8mA CT, 6.3V@1.2A)	
54-171	Power Transformer (P: 120V; S: 28V CT@1.6A)	GR-104
54-172	Power Transformer (P: 120V; S: 18V@20mA)	
54-173	Power Transformer (P: 120V; S: 26V@400mA CT)	
54-176	Power Transformer (P: 120V; S: 100V@280mA CT, 57V@200mA, 6V@2A)	
54-177	Power Transformer (P: 120/240V; S: 15V@14mA)	GD-39, GD-49, GRA-88-1, IM-16, IM-25
54-178	Power Transformer (P: 120V; S: 34V@34mA)	
54-179	Power Transformer (P: 120V; S: 248V@150mA, 105V@30mA, 6.3V@5.5A)	HW-16, (SB-400, SB-401 ?)
54-179-24	Power Transformer (P: 120/240V; S: 260V, 110V@30mA, 6.3V@2A)	DX-60B
54-180	Power Transformer (P: 115/230V; S: (10, 15, 20, 25, 29, 33, 38, 43, 47, 53V)@1.5A, 170V@43mA, 7.1V@32mA)	IP-27
54-181	Power Transformer (P: 120/240V; S: 100V@280mA CT, 57V@200mA, 6V@2A)	AA-15, AR-15
54-182	Power Transformer (P: 120/240V; S: 600V@1mA, 215V@25mA, 6.3V@3A, 6.3V@600mA)	SB-610, SB-614, SB-620
54-184	Filament Transformer (P: 115/230V; S: 12.6V@2A CT, 6.3V2A, 6.3V@600mA, 6.3V)	IP-17, SP-2717A
54-185	Power Transformer (P: 115/230V; S: 600V@30mA CT, 210V@120mA, 175V@15mA)	IP-17, SP-2717A
54-186	Power Transformer (P: 120V; S: 50V@900mA CT)	AR-17
54-187	Power Transformer (P: 120V w/ 2 Taps; S: 6V@4.3A)	GH-17A
54-189	Power Transformer (P: 120V; S: 315V@450mA, 6.3V@14A, 6.3V@1A)	
54-190	Power Transformer (P: 120V; S: 41V@220mA CT, 13.6V@650mA CT)	
54-191	Power Transformer (P: 120V; S: 41V@1mA CT, 13V@12mA)	IG-57, IG-57A, IG-5257
54-192	Power Transformer (P: 120V; S: 100V@320mA)	
54-193	Power Transformer (P: 120V; S: 33V@450mA CT)	
54-194	Power Transformer (P: 120V; S: 13V@75mA, 6.5V@12mA)	GD-77, GD-87
54-195	Power Transformer (P: 120/240V; S: 980V@40mA w/ Taps @ 300 & 600V, 6.3V@2.5A, 6.3V@600mA)	IO-17
54-196	Power Transformer (P: 120V; S: 75V@33mA CT, 73V@30mA CT, 52V@130mA CT)	
54-197	Power Transformer (P: 120/240V; S: 139V@150mA, 12.6V@1A, 12V@1.5A)	HW-17
54-198	Power Transformer (P: 120/240V; S: 282V@250mA, 125V@150mA w/ Tap @95V, 12.6V@5.5A CT)	HP-23A, SB-401
54-199	Power Transformer (P: 120/240V; S: 43V@350mA CT, 6V@1.8A)	AJ-15
54-200	Inv. Transformer (S: 340V@150mA)	
54-201	Power Transformer (P: 120/240V; S: 36V@60mA CT)	AA-18
54-202	Inv. Transformer (S: 5V CT)	MP-14
54-203	Inverter Transformer (300V@2.6A MT)	MP-14
54-204	Power Transformer (P: 120V; S: 100V@40mA, 33.8V@34mA, 6.3V@1.5A)	
54-205	Power Transformer (P: 120/240V; S: 82V@60mA CT)	IG-18
54-206	Power Transformer (P: 120V; S: 275V@50mA CT, 38V@500mA CT, 23V@2A CT)	

P/N	Description	Used In
54-211	Power Transformer (P: 120V; S: 85V@20mA, 46.5V@200mA CT, 45V@100mA CT, 16V@200mA)	
54-212	Power Transformer (P: 120V; S: 39V@500mA CT, 31V@10mA)	
54-213	Power Transformer (P: 120V; S: 160V, 26V@50mA)	
54-214	Power Transformer (P: 120V; S: 117V@150mA, 12.6V@2.7A)	
54-215	Power Transformer (P: 120V; S: 1402V@90mA MT, 49V@140mA CT, 47V@27mA CT, 6.3V)	
54-216	Power Transformer (P: 120V; S: 41V@220mA CT, 13.6V@650mA CT)	
54-217	Power Transformer (P: 120V; S: 220V@300mA CT, 220V@3mA, 50V@50mA CT, 2.6V)	
54-219	Power Transformer (P: 120V; S: 38V@22mA CT)	
54-220	Power Transformer (P: 120V; S: 780V@4mA, 118V@10mA, 95V@10mA, 6.2V)	
54-221	Power Transformer (P: 120V; S: 680V@50mA CT, 56V@31mA CT)	
54-222	Power Transformer (P: 120V; S: 143V@45mA CT, 9.3V@2A)	
54-223	Power Transformer (P: 120V; S: 33V@370mA CT, 33V@120mA CT)	
54-224	Power Transformer (P: 120V; S: 41V@50mA CT)	
54-226	Power Transformer (P: 120/240V; S: 6V@50mA)	GR-78
54-227	Power Transformer (P: 120/240V; S: 41V@110mA CT, 19V@12mA)	
54-228	Power Transformer (P: 120/240V; S: 74V@1A CT, 72V@10mA)	IP-28
54-229	Power Transformer (P: 120/240V; S: 135V, 46V, 45V, 16V)	
54-230	Power Transformer (P: 120V; S: 50V@150mA CT, 48V@130mA CT, 6V@1.2A)	AR-19
54-231	Power Transformer (P: 120V; S: 330V@70mA, 175V@180mA, 60V@5mA)	
54-232	Power Transformer (P: 120V; S: 48V@130mA CT, 39V@200mA CT, 6V@1.2A)	AR-19, AR-1302
54-233	Power Transformer (P: 120/240V; S: 33V CT@450mA)	HWA-7-1, IG-28
54-234	Power Transformer (P: 120V; S: 37V@26mA, 34V@30mA CT, 21V@280mA CT)	
54-235	Power Transformer (P: 120/240V; S: 49V@20mA CT, 13V@1mA CT)	
54-236	Power Transformer (P: 120V; S: 420V@22mA, 22V@8mA, 6.3V@1A CT)	
54-237	High-Voltage Transformer (P: 120/240V; S: 800V@500mA)	HL-2200, SB-220, SB-221
54-238	Low-Voltage Transformer (P: 120/240V; S: 89V@60mA, 5V@30A CT)	HL-2200, SB-220, SB-221
54-239	Power Transformer (P: 120V; S: 258V@40mA)	
54-240	Auto-Transformer (P: 120V; S: 120V@1.7A)	
54-241	Power Transformer (P: 120V; S: 5V@2.5A CT)	
54-242	Power Transformer (P: 120/240V; S: 50V@200mA CT)	IM-5248, IM-5258, SB-303
54-243	Power Transformer (P: 120V; S: 201V@790mA, 82V@250mA CT, 5V@300mA)	GR-681
54-244	Power Transformer (P: 120V; S: 20V@700mA CT)	
54-245	Power Transformer (P: 120V; S: 660V@4mA, 95V@15mA, 6.3V@1.2A)	
54-246	Power Transformer (P: 120V; S: 3500V@400mA, 4.7V@20A)	
54-248	Power Transformer (P: 120/240V; S: 684V w/ Taps @ 660V@3mA & 672V, 26V@450mA CT, 6.3V@600mA)	IO-101
54-249	Power Transformer (P: 120V; S: 28V@450mA CT)	IG-5228
54-250	Power Transformer (P: 120V; S: 49V@200mA CT)	
54-251	Power Transformer (P: 120V; S: 198V@35mA, 98V@600mA, 6.3V@800mA)	
54-252	Power Transformer (P: 120V; S: 1000V@2mA MT, 430V@40mA MT, 300V@850mA CT, 60V)	IO-105
54-253	Power Transformer (P: 120V; S: 690V@60mA CT, 6.3V@2A)	
54-254	Power Transformer (P: 120V; S: 48V@160mA CT, 6V@1.7A)	
54-257	Power Transformer (P: 120/240V; S: 28V@79mA CT)	IPA-5280-1
54-258	Power Transformer (P: 120/240V; S: 1500V@1mA, 230V@100mA, 50V@100mA, 6.3V, 1Vpp)	IO-102
54-259	Power Transformer (P: 120V; S: 32V@500mA CT, 20V@1A CT, 16V@20mA)	
54-260	Power Transformer (P: 120/240V; S: 158V@40mA, 12.6V@730mA CT)	IB-101
54-261	Power Transformer (P: 120V; S: 134V@4mA, 37V@120mA CT, 6.3V@150mA)	

P/N	Description	Used In
54-262	Power Transformer (P: 120V; S: 23V@150mA)	
54-263	Power Transformer (P: 120V; S: 24V@600mA)	
54-264	Power Transformer (P: 120V; S: 64V@200mA CT, 48V@130mA CT, 6V@1.2A)	
54-265	Power Transformer (P: 120V; S: 20V@700mA CT)	
54-266	Power Transformer (P: 120V; S: 6V@400mA CT)	GD-206
54-267	Power Transformer (P: 120V; S: 46V@1.5A CT)	
54-268	Power Transformer (P: 120V; S: 23V@370mA CT)	
54-269	Power Transformer (P: 120V; S: 27V@1.5A)	
54-270	Power Transformer (P: 120/240V; S: 33V@50mA CT, 16V@1.2A CT)	SM-104A, SM-105A
54-271	Power Transformer (P: 120/240V; S: 40V@500mA CT)	IG-1271
54-272	Power Transformer (P: 120/240V; S: 18V@250mA CT, 15V@300mA)	IB-102
54-273	Power Transformer (P: 120/240V; S: 48V@100mA CT, 31V@75mA CT)	
54-274	Power Transformer (P: 120/240V; S: 132V@4mA, 36.5V@400mA, 32V@10mA CT, 22V CT, 7V CT)	IR-18M
54-275	Filament Transformer (P: 120V; S: 6V@900mA)	GR-681
54-276	Power Transformer (P: 120V; S: 36V@90mA CT)	
54-277	Power Transformer (P: 120V; S: 134V@4mA, 38V@450mA CT)	
54-280	Power Transformer (P: 120V; S: 25V@10A CT)	
54-281	Power Transformer (P: 120V; S: 21V@25mA, 10V@75mA CT)	
54-282	Power Transformer (P: 120/240V; S: 700V@3mA, 6.3V@600mA)	IO-1128, IO-4541, IO-4540, IO-4560
54-283	Power Transformer (P: 120/240V; S: 105V@7mA, 55V@68mA CT, 13V@280mA CT)	IM-102
54-284	Power Transformer (P: 120/240V; S: 1000V@2mA MT, 430V@40mA MT, 300V@85mA MT, 60V)	IO-105
54-285	Power Transformer (P: 120/240V; S: 650V@1mA, 160V@100mA, 36V@250mA, 2 x 6.3V, 1Vpp)	IO-103
54-286	Power Transformer (P: 120/240V; S: 75V@25mA, 37V@110mA, 8V@3A)	IB-1102
54-287	Converter Transformer 27/1 (P: CT; S: 600V)	CI-1040
54-288	Power Transformer (P: 120V; S: 20V@700mA CT)	
54-289	Power Transformer (P: 120V; S: 30V@1.5A CT)	
54-291	Power Transformer (P: 120/240V; S: 35V@40mA CT, 17V@3A CT)	AJ-1510A
54-292	Power Transformer (P: 117V; S: 53V@20mA CT)	AD-2002
54-293	Power Transformer (P: 120V; S: 160V, 26V@70mA)	
54-294	Power Transformer (P: 120V; S: 275V@25mA, 31V@750mA CT, 9V@220mA CT)	
54-295	Power Transformer (P: 120V; S: 58V@4.5A CT, 47V@130mA, 5V@500mA)	AA-2010
54-296	Power Transformer (P: 120V; S: 30V@5mA, 20V@600mA, 12V@75mA)	
54-297	Power Transformer (P: 120V; S: 10V@100mA)	
54-298	Power Transformer (P: 120/240V; S: 170V@10mA, 17.5V@1A CT)	SB-650
54-299	Power Transformer (P: 120V; S: 195V@20mA, 35V@75mA CT, 17V@650mA CT)	
54-503	Power Transformer (P: 205/225/245V; S: w/ Taps @ 360V & 720V@80mA, 1410V@3mA; 6.3V@3.5A CT, 6.3V@600mA, 5V@3A)	O-12U
54-504	Power Transformer (P: 240V; S: 160V, 6.3V)	AW-1U
54-507	Power Transformer (P: 100/200/220/240V; S: 550V CT, 6.3V)	RA-1
54-509	Power Transformer (P: 240V)	AV-3U
54-512	Mains Transformer (P: 105/125/205/225/245V; S: HV CT, 6.3V)	FM-4U
54-516	Power Transformer	OS-1
54-520	Power Transformer (P: 100/200/220/240V; S: 556V CT, 6.3V, 5V)	MA-12
54-522	Power Transformer (P: 240V; S: 150V, 6.3V)	RF-1U
54-525	Mains Transformer (P: 110/205/225/245V; S: 520V CT, 6.3V)	AO-1U
54-534	Power Transformer (P: 120/240V)	HFW-1
54-801	Power Transformer (P: 120/240V; S: 747V@1mA, 239V@20mA, 43V@50mA CT, 6.3V)	CO-1015
54-802	Power Transformer (P: 120V; S: 20V@350mA CT)	
54-803	Power Transformer (P: 120V; S: 7V@300mA)	

P/N	Description	Used In
54-804	Power Transformer (P: 120V; S: 36V@200mA CT)	AA-1219
54-805	Power Transformer (P: 120/240V; S: 66V@450mA CT)	AJ-1214
54-806	Inverter Transformer (S: 125V@150mA)	
54-807	Power Transformer (P: 120/240V; S: 282V@250mA, 125V@150mA w/ Tap @95V, 12.6V@5.5A)	HP-23, HP-23C, PS-23
54-808	Power Transformer (P: 120V; S: 13V@65mA)	
54-809	Power Transformer (P: 120V; S: 35V@100mA, 6V@500mA)	
54-810	Power Transformer (P: 120V; S: 165V@15mA, 18V@55mA)	
54-811	Power Transformer (P: 120V; S: 33V@150mA CT, 16V@2.5A CT)	
54-812	Power Transformer (P: 120V; S: 660V@100mA CT, 6V@4.5A CT, 6V@600mA)	
54-813	Power Transformer (P: 120V; S: 42V@400mA)	
54-814	Filament Transformer (P: 120V; S: 27V@10A)	
54-815	Power Transformer (P: 120/240V; S: 105V, 30V, 5V)	IM-1202
54-816	Power Transformer (P: 120/240V; S: 195V@20mA, 35V@75mA CT, 14V@650mA CT)	IB-1100
54-818	Power Transformer (P: 120V; S: 20V@2.2A)	
54-819	Converter Transformer 4/1	
54-820	Power Transformer (P: 120/240V; S: 170V@15mA, 18.5V@55mA)	GC-1005
54-821	Power Transformer (P: 120V; S: 850V@1mA, 135V@120mA CT, 19V@1A CT, 8V)	
54-822	Power Transformer (P: 120V; S: 134V@4mA, 38V@40mA)	
54-823	Power Transformer (P: 120V; S: 220V@300mA CT, 220V@3mA, 115V@250mA, 50V@50mA)	
54-824	Power Transformer (P: 120V; S: 36V@3.5A CT)	AA-2005
54-825	Power Transformer (P: 120/240V; S: 17V@1.4A CT, 15V@20mA)	SM-118A
54-826	Power Transformer (P: 120V; S: 120V@10mA MT, 1.3V@450mA)	
54-827	Power Transformer (P: 120V; S: 5V@450mA)	
54-828	Power Transformer (P: 120/240V; S: 16V@70mA)	IC-2009
54-829	Isolation Transformer (P: 115V; S: 115V@430mA)	
54-830	Power Transformer (P: 120V; S: 16V@50mA)	HW-2021, HW-2031
54-831	Power Transformer (P: 120V; S: 150V@10mA, 18V@75mA)	
54-832	Power Transformer (P: 120V; S: 32V@500mA CT, 20V@1A CT, 16V@20mA)	
54-833	Power Transformer (P: 120V)	ID-1290
54-834	Power Transformer (P: 120V; S: 8V@1.7A, 20V@100mA)	
54-835	Power Transformer	GR-2000
54-836	Power Transformer (P: 120V; S: 5.5V@900mA)	GR-2050
54-837	Power Transformer (P: 120V; S: 1200V w/ Tap, 40V CT, 6.3V, 1Vpp)	AD-1013
54-839	Power Transformer (P: 120/240V)	IT-1121
54-840	Power Transformer (P: 120/240V; S: 75V, 37V, 8V)	IB-1103
54-847	Power Transformer (P: 120/240V)	SB-230
54-848	Power Transformer (P: 120/240V)	HP-1144, HP-1144A, IP-2715
54-859	Power Transformer (P: 120V; S: 374V CT, 34V CT)	GC-1092A, GC-1092AE, GC-1092D
54-861	Transformer (25kHz)	SB-104, SB-104A
54-866	Power Transformer (P: 120/240V; S: 250V, 30V, 12V CT)	IM-1212, IMD-202-2
54-868	Power Transformer (P: 120/240V; S: 374V CT, 34V CT)	GC-1092A, GC-1092AE
54-870	Power Transformer (P: 120/240V)	SB-634
54-878	Power Transformer (P: 120/240V)	HD-1410
54-880	Low Voltage Transformer (P: 120/240V; S: 150V, 23V, 1V P-P)	IO-4541, IO-4560
54-884	Power Transformer (P: 120V; S: 250V CT, 68V CT, 6V)	AA-1640
54-891	Power Transformer (P: 120/240V; S: 120V@650mA)	
54-892	Power Transformer (P: 120/240V; S: 30V CT)	ET-3100
54-893	Power Transformer (P: 120/240V)	ET-3200
54-894	Power Transformer (P: 120/240V)	CO-2600
54-897	Power Transformer (P: 120V; S: 128V)	IP-5220
54-898	Variable Transformer (P: 120V; S: 0-132V)	IP-5220

P/N	Description	Used In
54-899	Power Transformer (P: 120/240V)	IM-4100, SM-4100
54-903	Power Transformer (P: 120/240V)	GR-1085
54-905	Power Transformer (P: 120/240V; S: 120V, 5V)	IG-4505
54-907	Power Transformer (P: 120/240V)	HP-1175
54-915	Power Transformer (P: 120/240V)	HR-1680, SA-1480
54-916	Power Transformer	AA-1515
54-918	Power Transformer (P: 120/240V)	IP-2718, SP-2718
54-919	Power Transformer (P: 120/240V)	IO-4555
54-920	Power Transformer (P: 120/240V)	ET-3300, ET-3400, ETA-3400
54-923	Power Transformer (P: 120/240V; S: 38V CT, 13.2V CT)	IG-1275
54-926	Power Transformer (P: 120/240V)	IM-5238, IT-5235, ST-5235
54-927	Power Transformer (P: 120/240V; S: 23V, 15V CT)	IM-1210, IM-1210F
54-928	Power Transformer (P: 120/240V; S: 18V CT)	GC-1195, GC-1197
54-931	Converter Transformer	CI-1098
54-934	Power Transformer (P: 120/240V)	IM-5225
54-937	Power Transformer (P: 110-120/220-240V; S: 240V CT w/ 2 Taps @ 100V, 34V CT, 16V CT, 6.3V)	IO-4235
54-939	Power Transformer (P: 120/240V)	H-10
54-940	Power Transformer (P: 120/240V)	H-8, H-17, H-77
54-943	Power Transformer (P: 120/240V)	H-9
54-945	Power Transformer (P: 120/240V)	H-11
54-948	Power Transformer	AA-1600
54-949	Power Transformer (P: 120/240V; S: 23V; 13V)	GC-1107, HWA-5400-1
54-950	Power Transformer (P: 120/240V; S: ?, 15V)	IT-5230
54-951	Power Transformer (P: 120V; S: 11V)	OCA-1401-1
54-952	Power Transformer (P: 120/240V; S: 23V, 16V CT)	IM-4110, IM-4120
54-953	Power Transformer (P: 120/240V; S: 350V, 120V, 20V CT, 6.3V, 1V)	IO-4105, IO-4205
54-954	Power Transformer (P: 120/240V; S: 76V CT, 12V)	AP-1800
54-957	Power Transformer (P: 120/240V)	AJ-1600
54-958	Power Transformer	AD-1701
54-959	Power Transformer (P: 120/240V; S: 16.5V CT, 8.2V CT)	ID-4001
54-961	Power Transformer (P: 120/240V; S: 33V CT)	IMA-4180-1
54-962	Power Transformer (P: 120/240V)	H-14
54-965	Power Transformer (P: 120/240V)	WH-19
54-969	Power Transformer (P: 120/240V)	H-88, H-89A, WH-89A, Z-89, Z-90
54-971	Main Power Transformer (P: 120/240V; S: 38V CT)	PS-9000
54-972	Clock Power Transformer (P: 120/240V; S: 16.5V)	PS-9000
54-977	Power Transformer (P: 120/240V; S: 34V CT, 17V)	ID-1990
54-978	Power Transformer (P: 120/240V)	IM-2410
54-982	Power Transformer (P: 120/240V)	IM-2420
54-984	Power Transformer (P: 120/240V)	AD-1702
54-987	Power Transformer (S: 26V CT@500mA, 18V@2.5A, 14V CT@2.5A)	
54-992	Power Transformer (P: 120V)	SA-2500
54-996	Power Transformer (P: 120/240V)	HWA-5400-1
54-1001	Power Supply	ZTX-1, ZTX-1-A, ZTX-1-B
54-1005	Power Transformer (P: 120/240V; S: ?V, 30V CT)	ET-3100B
54-1007	Power Transformer (P: 120/240V)	IG-4244
54-1010	Power Transformer (P: 120/240V)	ET-1000, ETW-1000
54-1013	Power Transformer (P: 120/240V)	GC-1000H
54-1015	Power Transformer	SA-2500
54-1016	Power Transformer	IG-1277
54-1020	Power Transformer (P: 120V)	GD-1530
54-1021	Power Transformer (P: 120V)	SW-7800
54-1022	Power Transformer (P: 120V)	PSA-9
54-1023	Power Transformer (P: 120/240V)	IT-2232

P/N	Description	Used In
54-1024	Power Transformer (P: 120V)	HD-3030
54-1028	Power Transformer (P: 110-120/220-240V; S: 200V CT w/ 2 Taps @ 78V, 26V CT, 12V CT, 6.3V, ?P1101)	IO-4360A
54-1031	Power Transformer (P: 120V)	HD-1481
54-1032	Power Transformer	IO-4210
54-1033	Power Transformer (32kHz)	ET-4200, ETW-4200
54-1034	Power Transformer (P: 120V)	HO-5404
54-1036	Power Transformer (P: 120V)	ID-4801, IT-2240
54-1039	Power Transformer (P: 120V; S: 16.5V CT, 9.5V CT)	ID-4850
54-1044	Power Transformer	IO-4225
54-1045	Power Transformer (P: 120V)	HD-4040
54-1054	Power Transformer (P: 120/240V)	ETW-3700, ETW-3800
54-1055	Power Transformer (P: 120/240V)	ETW-3567
54-1059	Power Transformer (P: 120/240V; S: 20V CT, 10.7V CT)	ID-5001, ID-5001B, IDW-5001C
54-1061	Power Transformer (P: 120/240V; S: 700V, 10.5V, 5.2V CT@15A)	SB-1000
54-1066	Logic Power Transformer (P: 120/240V)	HD-1780, HDW-1780
54-1067	Rotator Power Transformer (P: 120/240V)	HD-1780, HDW-1780