SCHEMATIC DIAGRAM



NOTE

1) Ss-1 ∿ Ss-7 SELECTOR SWITCH 1-AM, 2-FM, 3-PHONO, 4-AUX 1, 5-AUX 2
2) Sp-1 ∿ Sp-6 SPEAKER SWITCH 1-OFF, 2-A, 3-QUATRA, 4-B, 5-A+B
3) ALL RESISTANCE VALUES ARE INDICATED IN "OHM" ($K=10^3$ OHM, $M=10^6$ OHM).
4) ALL CAPACITANCE VALUES ARE INDICATED IN "μF" ($P=10^{-6}\mu$F).

www.hifiengine.com