


## ADDENDUM SHEET – CITATION II

Before proceeding with the construction of your kit, please make the following changes in your assembly and operation manual.

A) Refer to page 10.

- 1) Change step 11 to read, "Hook cathode lead from SD1 with anode lead from SD2 (NS). Do not cut off excess wire. Fragile! Use caution handling leads." (See addendum pictorial, detail A.)

### DETAIL A




- 2) Change step 12 to read, "Hook anode lead from SD3 with cathode lead SD4 (NS). Do not cut off excess wire."

B) Insert the following 4 steps directly after step 16 on page 10.

- 3) Twist a pair of 2.2 megohm  $\frac{1}{2}$  watt 10% resistors (red, red, green, silver) together as shown in addendum pictorial, detail B. Slip a small piece of sleeving over the twisted leads.

### DETAIL B



- 4) Connect the twisted leads of the pair of 2.2 megohm  $\frac{1}{2}$  watt 10% resistors (red, red, green, silver) through the loop of SD1 and SD2 (S). Cut off excess wire. Connect one free end of the pair of resistors to T5 lug #1 (NS) and connect the other free end to T5 lug #2 (NS). See addendum pictorial, detail C.

### DETAIL C

